



### PARTS LIST 01/2000

KEY N.	DESCRIPTION	QUANT.
01	CIRCLIP	1
02	S.STEEL CAP	1
04	PLASTIC CAP	1
16	DRUM	1
17	BASE ROLLER BEARING	1
18	PLASTIC SPACER	1
19	BASE ROLLER BEARING	1
21	STEM	1
22	PLASTIC WASHER (W43/W46)	1
	S.STEEL WASHER (W52/W60)	1
23	SCREW	4
24	S.STEEL WASHER	4
25	BASE	1
26	SHAFT ROLLER BEARING	1
28	PLASTIC SPACER	1
29	S.STEEL SHAFT	1
30	SHAFT ROLLER BEARING	1
31	S.STEEL RING	1
32	PAWL	6
33	PAWL SPRING	6
34	BRONZE GEAR "A2"	1
35	PLASTIC CAP	1
36	SCREW	1
37	SKIRT	1
39	BRONZE GEAR "D1"	1
40	BRONZE GEAR "D2"	1
43	BRONZE GEAR "B2"	1
44	BRONZE GEAR "B1"	1
46	S.STEEL BALL BEARING	1
47	S.STEEL WASHER	1
48	PLASTIC WASHER	1
49	S.STEEL SPINDLE	1
50	PLASTIC WASHER	1
51	PLASTIC WASHER	1
52	S.STEEL SPINDLE	1
53	PLASTIC WASHER	1
54	SEGER	1
55	S.STEEL WASHER	1
56	S.STEEL PIN	2