



PARTS LIST 11/2002

KEY N.	DESCRIPTION	QUANT.
01	CIRCLIP	1
02	S.STEEL CAP	1
03	SCREW	2
04	BRONZE CAP	1
05	SCREW	2
06	ST ARM	1
07	BRONZE ST RING	1
08	PLASTIC ST RING	1
09	SCREW	6
10	S.STEEL WASHER	6
11	ST SPRING	6
12	S.STEEL WASHER	6
13	S.STEEL PIPE	6
14	UPPER ST DISK	1
15	SCREW	6
16	UPPER B.B. TRACK	1
17	TORLON BALLS 13/32"	62
18	LOWER B.B. TRACK	1
19	SCREW	2
20	STRIPPER	1
21	PLASTIC PLUG	12
22	SCREW	6
23	LOWER ST DISK	1
24	TORLON BALLS 13/32"	47
25	INNER B.B. TRACK	1
26	SCREW	3
27	DRUM	1
28	UPPER ROLLER BEARING	1
29	PLASTIC SPACER	1
30	LOWER ROLLER BEARING	1
31	BRONZE HALF RING	2
32	STEM	1

PARTS LIST 11/2002

KEY N.	DESCRIPTION	QUANT.
33	SCREW	8
34	STEM BASE	1
35	FORK STAND	1
36	S.STEEL WASHER	2
37	SCREW	2
38	SCREW	1
39	S.STEEL WASHER	1
40	FORK	1
41	FORK PIN	2
42	FORK AXIS	1
43	S.STEEL WASHER	2
44	NUT	2
45	FORK LEVER	1
46	S.STEEL TRACK	1
47	SHAFT ROLLER BEARING	2
48	BEARING SPACER	1
49	BRONZE HALF RING	2
50	MAIN SHAFT (UPPER)	1
51	BRONZE GEAR "A3"	1
52	BRONZE GEAR "A2"	1
53	PLASTIC WASHER	1
54	PAWL SPRING	9
55	XANTAL PAWL H13	3
56	MAIN SHAFT (LOWER)	1
57	S.STEEL WASHER	1
58	SHAFT ROLLER BEARING	1
59	S.STEEL TRACK	1
60	S.STEEL SPACER	2
61	GEAR BASE	1
62	SCREW	3
63	SKIRT	1
64	S.STEEL TRACK	2
65	ROLLER BEARING	2
66	BRONZE GEAR "D2"	1
67	BRONZE GEAR "D1"	1
68	GEAR "D1" CAP	1
69	SCREW	3
70	DELTRIN BALL 3/16"	38
71	PLASTIC WASHER	1
72	PLASTIC SPACER	1
73	BRONZE GEAR "E2"	1
74	ROLLER BEARING	3
75	S.STEEL SPINDLE "E"	1
76	PLASTIC WASHER	1
77	PLASTIC WASHER	1
78	BRONZE GEAR "B2"	1
79	XANTAL PAWL H20	6
80	BRONZE GEAR "B1"	1
81	GEAR "B1" CAP	1
82	SCREW	4
83	ROLLER BEARING	4
84	BEARING SPACER	1
85	S.STEEL SPINDLE "B"	1
86	PLASTIC WASHER	1
87	GEAR BALL BEARING	1
102	KNOB	1
103	KNOB SCREW	3

